



| ITEM NO. | PART NO. | DESCRIPTION                                  | QTY REQ'D | ITEM NO. | PART NO. | DESCRIPTION                                     | QTY REQ'D |
|----------|----------|--|-----------|----------|----------|---|-----------|
| 1        | S01628   | Field Assembly                               | 1         | 17       | 01614    | Actuating Arm                                   | 1         |
| 2        | 01160    | Field Mounting Screw                         | 2         | 18       | 02048    | Adjusting Screw                                 | 1         |
| 3        | 01059    | Field Screw Lockwasher                       | 2         | 19       | 01716    | Stabilizer Screw                                | 1         |
| 4        | 03998    | Swivel Stud Screw                            | 1         | 20       | 02047    | Stabilizer Spring                               | 1         |
| 5        | 01077    | Armature Link                                | 1         | 21       | 01616    | Hanger Bail                                     | 1         |
| 6        | 01070    | Top Swivel Stud Washer                       | 2         | 22       | 01615    | Switch Button                                   | 1         |
| 7        | 01296    | Internal Washer (used with 3-wire cord only) | 1         | 23       | 03001    | Adjusting Lever Tension Spring                  | 1         |
| 8        | 17069    | Mounting Plate Screw                         | 1         | 24       | 01626    | Adjusting Lever                                 | 1         |
| 9        | 06009    | Ground Screw (used with 3-wire cord only)    | 1         | 25       | 03005    | Ball Pin  | 1         |
| 10       | 01583    | Cord Retaining Clip                          | 1         | 26       | 01581    | Blade Pad and Guide Assembly                    | 1         |
| 11       | 01643    | 2-Wire Cord (ML Clipper)                     | 1         | 27       | 01053    | Lower Blade Screw                               | 2         |
| 12       | 01648    | 3-Wire Cord (ML-CSA / GC-UL/CSA)             | 1         | 28       | 17808    | Blade Pad Assembly Screw                        | 4         |
| 13       | 01655    | Switch Assembly                              | 1         | 29       | 01147    | Blade Guard                                     | 1         |
| 14       | 01699    | Cover Screw                                  | 2         | 30       | S01641   | Armature Assembly (incls. Items 31, 32, 33, 35) | 1         |
| 15       | 01629    | Cover (ML -UL)                               | 1         | 31       | 01400    | Connector Fork                                  | 1         |
|          | 01288    | Cover (ML -CSA)                              | 1         | 32       | 01213    | Connector Fork Washer                           | 1         |
|          | 01295    | Cover (GC -UL)                               | 1         | 33       | 03904    | Connector Fork Screw                            | 2         |
|          | 01702    | Cover (GC -CSA)                              | 1         | 34       | 03021    | Bottom Swivel Stud Washer                       | 1         |
| 16       | 01639    | Switch Insulation                            | 1         | 35       | 13040    | Armature Adjusting Screw                        | 1         |

## IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of clipper. For best performance, clipper should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin 53177 U.S.A. Carefully pack and mail either insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.